

Advantages of motor actuated ball valves of EMV110..series with incorporated relay module for solar heating systems

In solar heating systems motor actuated ball valves can prevent various inconveniences.

- Effectively prevent hydraulic shocks in systems as they require 30 seconds for complete opening.
- Due to their shape they do not impede the flow.
- Springs are not included, therefore noise does not appear.
- When closed, 100% sealing is guaranteed.
- They have an output for pump up to 100 W in open position, therefore they do not present a hydraulic load for pump in closed position. They enable pump switching on only in completely open position.
- Due to installed RELAY module they enable control with make contact only.
- If during closing or opening process impurities enter in valve, which could block it, the valve stops and immediately afterwards continues with opening or closing process in opposite direction, so that water flow can rinse the impurities up to cleaning net (anti-blocking system).

EMV 110 602/4230



EMV 110 502/7930



EMV 110 316/8910



FIRŠT®

Differential thermostat for regulation of two heating circuits in combination of solar and classic heating with temperature display and regulation of burner or electric heating element

DTC 100/4 TD

***User's manual
Installation and maintenance instructions***

FIRŠT-ROTOTEHNIKA, s.p.
Radegunda 54, SI-3330 MOZIRJE
SLOVENIJA

tel. +386 3 898 35 00
fax. +386 3 898 35 35
e-mail: info@rototehnika-sp.si

DEAR CUSTOMER

Congratulations !

You have bought a DTC 100/4TD differential thermostat, manufactured according to the latest quality and safety standards. It is made according to the state of art and efficiently utilises solar energy or alternative sources for domestic water heating.

It is designed in compliance with strict criteria and requirements of West European markets and enables efficient use of solar energy which enables considerable savings of other sources for domestic water heating.

Our products are available in the markets for several years and satisfy the needs of demanding customers from hot Greece to north Germany.

We are convinced that the use of our product will satisfy your needs too and help you to save your money.

Thanks for your confidence !

FIRŠT Rototehnika

The set consist of:

1. Differential thermostat DTC 100/4TD
2. T1 collector sensor with silicone conductor
3. T2 hot water tank sensor with PVC conductor
4. T3 sensor for installation in boiler or to upstream conduit in front of mixing valve (PVC)
5. T4 hot water tank sensor with PVC conductor
6. Fixing screws with wall inserts (2 pcs)
7. Clip for T4 sensor fastening with fixing springs
8. Instructions for use
9. Warranty certificate

In case any of these are missing or damaged, demand your seller to supply you with a replacement.

Read these instructions carefully, as this will allow you to benefit from all the possibilities offered by this product.

WARNING !

All examples listed in the instructions are merely indicative. The manufacturer accepts no responsibility for incorrect hydraulic connection of machine part of installation.


Machine and electric installations should comply with all safety regulations defined by law and the rules.

We reserve the right to modify the instructions and the technical data of the product without prior notice

Trouble-shooting guide

TROUBLE	POSSIBLE FAILURE	REMEDY
Thermostat inoperative	Plug not connected	Connect plug in socket
Water cools down during night	-Selector switch not in AUTO position -One of retaining valves of the system inoperative (enables thermosiohon water circulation)	-Set the switch to AUTO position -Check machine installation We recommend installation of motor actuated ball valve "EMV110.."
When pumps are active, unplesant noise in installation is heard	Retaining valve makes noise (weak spring)	Replace nonreturn valve with motor actuated ball valve "EMV110.."
Irrespective of the temperatures, all pumps are inoperative	Selector switch in position "OFF" Temperature limit of hot water tank too low	Set selector switch to AUTO position Increase max. temperature in hot water tank (see: Temperature regulation in hot water tank)
Irrespective of the temp., collector pump is continuously switched on and after-heating pump is inoperative	Selector switch in "ON1" position	Set the switch to AUTO position
Irrespective of the temp., after-heating pump is continously switched on and collector pump is inoperative	Selector switch in "ON2" position	Set selector switch to AUTO position
Collector pump operates normally and after-heating pump not	After-heating circuit disconnected	Connect after-heating circuit See: Settings
After-heating pump operates normally and collector pump not	Collector circuit disconnected	Connect collector circuit See: Settings
Control light of individual pump is on, but the pump is inoperative	Pump blocked or cable of the pump interrupted	Check the pump and connection to regulator
When "T1" key is pressed Er1 appears	T1 sensor is interrupted	Check T1 sensor
When "T1" key is pressed Er2 appears	T1 sensor is short circuited	Check T1 sensor
When "T2" key is pressed Er1 appears	T2 sensor is interrupted	Check T2 sensor
When "T2" key is pressed Er2 appears	T2 sensor is short circuited	Check T2 sensor
When "T3" key is pressed Er1 appears	T3 sensor is interrupted	Check T3 sensor
When "T3" key is pressed	T3 sensor is short circuited	Check T3 sensor

HOLES FOR EASIER INSTALLATION OF DIFFERENTIAL THERMOSTAT ON WALL



GENERAL

DTC 100/4TD is a microprocessor aided double differential thermostat, designed for heating of domestic water from two heating sources (collectors, boilers, heat pumps,...), using its logic of additional energy source switching on (boiler of central heating system). The thermostat controls two pumps or two motor actuated ball valves (EMV 110..) and one burner or electric heating element.

The thermostat enables regulation of four parametres, i.e.:

1. Regulation of maximum temperature in hot water tank from 10 to 90°C.
2. Regulation of difference for higher exchanger from 2 to 15° (after-heating circuit)
3. Regulation of difference for lower exchanger from 2 to 15° (collector circuit)
4. Setting two working regimes - C.n.b (normal) and C.d.t. (switching off the limitation of boiler temperature for collector circuit).

With first two regulation options you define how much the value of the source temperature (collector, boiler,...) should exceed the temperature of water around the exchanger in hot water tank, that the regulator activates the pump or opens the valve.

The difference is set in relation to the volume of heat losses of the system which depend on lengths of pipelines from source to hot water tank and on pipeline insulation.

Built-in digital display enables prompt reading of the temperatures of individual sensors and of all set values as well.

OPERATION:

DTC 100/4TD double differential thermostat measures the temperature of two heating sources (collectors, boiler, ...) and of two spots in user (hot water tank). Heating effect is provided, when heating unit (heating element in hot water tank) exceeds the temperature of the user (water in hot water tank) for at least 3 - 5°. Consequently minimum adjustable difference is 2° (factory set to 5°).

When the temperature of the source exceeds the temperature around the exchanger for at least 5°, the thermostat opens the valve (EMV...) or activates the pump; it closes the valve or stops the pump, when temperature difference is one degree lower than pre-set value.

The thermostat also switches off a pump if pre-set temperature is reached in hot water tank (adjustable from 10 to 90°C).

If gas flow boiler, oil boiler or electric heating element (which is switched off during summer seasons), is connected to after-heating circuit, the regulator can switch on the boiler by means of the third output, if domestic water is to be additionally heated by means of after-heating circuit. In summer seasons a few days of cloudy weather can appear or use of domestic water increases. In such cases domestic water is to be after-heated from additional source (central heating system boiler or electric heating element). Classic differential thermostat would require hot boiler throughout the year, which is not recommended from ecological and economic point of view. DTC 100/4TD, with its third additional output, enables activation of after-heating source. When after-heating of water is required, regulator first switches on the burner of the boiler and when the condition of difference for after-heating circuit is also assured (pre-set difference of boiler has higher temperature than hot water tank), pump is switched on.

When pump operates for primary heating circuit (collectors), operation of after-heating circuit and burner of boiler or electric heating element is prevented. This assures maximum energy savings during summer seasons and is also the main role of solar systems. The set comprises four sensors (T1, T2, T3, T4). Two of them are mounted into individual heating sources and two into upper half of individual exchangers in hot water tank. T1 and T2 are designed for primary (main) heating circuit which heats entire quantity of water in hot water tank (lower exchanger), where T1 is a sensor of heating source (generally collectors) and T2 is a sensor in lower part of hot water tank. T3 and T4 are designed for additional, i.e. after-heating circuit which additionally heats water in hot water tank (upper exchanger). T3 is a sensor of heating source (generally boiler) and T4 is a sensor in upper part of hot water tank.


TEHNIICAL DATA:

Supply voltage	230V, 50Hz +/- 10%
Power consumption	4 VA
Pump relay rating	3A/230VAC cos 0.6
Type of thermostat	P
Max. measured temperature	180°C
Min. measured teperature	-20°C
Adjustable temperature range	10 - 90°C
Temperature difference settings	2 - 15°C
Hysteresis of difference	2°K
Hysteresis of the thermostat	3°K
Nr. of sensors	4
Nr. of outputs	3 (230 VAC delovni)


INSTALLATION OF THERMOSTAT:

Install the thermostat on hot water tank casing or close to it. Do not mount it under pipe fittings or valves due to possible water dripping on its housing.


EXTERNAL CONNECTIONS:



CONNECTION OF ELECTRIC HEATING ELEMENT





BURNER CONTROL



WARNING:
 Before opening, unplug from power supply.
 Only qualified person can maintain the apparatus.

Water After-heating with Electric Heating Element

When water is after-heated by means of electric heating element, it must be connected through additional power relay and safety immersion thermostat. T4 sensor should be installed above electric heating element.



DTC
Differential thermostat
DTC 100/4TD

T1, T2, T3, T4

Sensors
T1 - collector sensor
T2 - hot water tank sensor
T3 - boiler sensor
T4 - hot water tank sensor



P1, P2
Circuit pump
P2 - primary circuit pump
P1 - after-heating circuit pump




EMV1, EMV2
Electric motor actuated ball valve:
EMV 110 602
EMV 110 502




electric heating element

Electric connection



ELECTRIC CONNECTION:



Grounding wires should be connected to special terminal pins situated on right side of terminal strips.

220-240V
50 Hz
L
N


TERMINAL	CONNECTION
1,2	T1 sensor – heating source sensor (collectors, boiler...)
3,4	T2 sensor – hot water tank sensor
5,6	T3 sensor – heating source sensor for higher heating circuit (boiler)
7,8	T4 sensor – hot water tank sensor in upper part of hot water tank neutral conductor
9	neutral conductor
10	phase for boiler (burner) switching on
11	neutral conductor
12	phase of pump for secondary heating circuit
13	neutral conductor
14	phase of pump for collector heating circuit
15	phase connector for mains 230V, 50 Hz
16	neutral conductor - connector for mains 230 V, 50 Hz

WARNING:


Boiler control should be performed behind the main switch for burner but in front of boiler thermostat. Care must be taken that differential thermostat and boiler connection are performed at the same phase otherwise inter-phase contact can occur.

SENSOR INSTALLATION IN COLLECTOR:

Install it as immersion sensor in collecting pipe at the top of the collectors in provided sleeve




For cables longer than 15m we recommend over-voltage protection with VDR resistor.




SENSOR INSTALLATION IN BOILER:

Built T3 sensor in a boiler as immersion sensor in front of mixing valve in upstream flow or next to boiler sensor in a sleeve. If this is not possible you can mount it as contact sensor in upstream flow in front of mixing valve. In such a case we recommend to isolate it.



SENSORS INSTALLATION IN HOT WATER TANK:

Install T2 and T4 sensors to provided place in hot water tank or on hot water tank wall under isolation as contact sensor in upper part of exchanger. When sensor is mounted as contact one we recommend to coat it with heat conducting paste or liquid metal.




In special purpose vertical or horizontal tube (sensor should be protected against accidental extraction).

On hot water tank with clip, wire and spring strip (use paste for better heat transmission).


In special purpose side tube (protect against extraction).

CONTROL PANEL




Connection with Two Pumps

In order to prevent water circulation, behind the pump a retaining valve should be installed. When conditions for heating a heating circuit are achieved, pump switches on.




Electric connection



Connection with two electric motor actuated ball valves

When conditions for heating of a heating circuit are achieved, EMV110...800 series, opens afterwards, when the valve is opened, pump switches on.



DTC
Differential thermostat
DTC 100/4TD



T1, T2, T3, T4
Sensors
T1 - collector sensor
T2 - hot water tank sensor
T3 - boiler sensor
T4 - hot water tank sensor




P1, P2
Circuit pump
P2 - primary circuit pump
P1 - after-heating circuit pump



EMV1, EMV2
Electric motor actuated ball valve:
EMV 110 602
EMV 110 502

Electric connection



THERMOSTAT REGULATION

The following settings are performed with keys situated under display:

- Maximum temperature in hot water tank.
- Difference of collector circuit.
- Difference of after-heating circuit (boiler).
- Setting two working regimes - C.n.b and C.d.t.
- Collector circuit operation switching off with automatic operation of after-heating circuit. (Used when liquid is discharged from collector system.)
- After-heating circuit operation switching off with automatic operation of collector circuit. (Used if after-heating circuit is not required.)

Simultaneously press once central and right keys under the display to enter in set-up meni

1. Temperature setting in hot water tank (10-90°C)

On the display appear "b" and current pre-set temperature of hot water tank (in our case 55°C). With keys T2 in T3 set required temperature.



Recommendation:

Set the temperature in hot water tank to least 10° lower value as boiler temperature in boiler is set.

Warning:

If you additionally heat water with heat pump, you must limit the water temperature to 55°C max. and connect output from terminal 12 and 14 through temperature safety fuse in hot water tank or through additional safety thermostat.

When you set the required temperature, press key T1 to pass over the next setting.



2. Setting of difference of collector circuit (0-15)

On the display appear "C" and current difference of collector circuit (factory set to 5°C).

With keys T2 in T3 set required difference.



The difference defines the value for which source temperature should exceed the temperature of the user (collectors or boiler: hot water tank) that the pump is activated. It is generally 5° for collectors and 8° for boiler (factory setting). Of course it depends on lengths and isolation of pipelines. If you decrease the difference to "0", collector circuit is switched off.

When you set the required temperature, press key T1 to pass over the next setting.



3. Setting of difference of after-heating circuit (0-15)

On the display appear "C" and current difference of collector circuit (factory set to 8°C).

With keys T2 in T3 set required difference.

If you decrease the difference to "0", after-heating circuit is switched off.

When you set the required temperature, press key T1 to pass over the next setting.



4. Setting the working regimes - C.n.b and C.d.t.

On the display appears signs "C.n.b." or "C.d.t."



Regime: C.n.b.

Normal state of thermostat. Limitations of temperatures valid for collector circuit and after-heating circuit. This regime must be used in systems with heat pump.

Regime: C.d.t.

Thermostat heats domestic water from collector circuit irrespective of setting of max. temperature in boiler (no limitation of max. temperature of the boiler for collector circuit). Choose that regime in case, that you want to use max. energy of collector and the crossing temperature of the boiler will not damage no one of connected consumer of hot water.

With keys T2 in T3 set required regime.

When you set the required regime, press key T1 and **hold it!**

On the display appears **P.r.** and hold down the key (approximately 3s), until the sign **P.r.** disappears and on display appears the temperature T1 (temperature of collector circuit). Now release the key.



If you release the key too soon, entered values are not effective.

We mentioned before, that we have the possibility to disconnect the collector circuit and after-heating circuit. For such step we decide in following cases:

Disconnection of Collector Circuit Operation

It is used in cases of mechanical faults of collector system which requires draining of liquid (water) from collector system, but after-heating circuit should operate in automatic mode. Disconnection is useful also in systems where water is discharged from collectors during winter, which prevents "dry operation" of the pump.

The procedure of disconnection is describe in point 2 - set the parameter C to value 0.

When you want again connection of the collector circuit, set the parameter C to value different from 0 (factory set to 5°C).

Disconnection of After-heating Circuit Operation

It is used in cases of mechanical faults of after-heating system which requires draining of liquid (water) from the system but collector circuit should operate in automatic mode. It disconnects after-heating pump operation as well as burner (or electric heating element) switching on.

The procedure of disconnection is describe in point 3 - set the parameter P to value 0.

When you want again connection of the after-heating circuit, set the parameter P to value different from 0 (factory set to 8°C).

WARNING!

If T2 and T3 keys are simultaneously pressed, you enter set-up menu. If in about 1 minute the values are not changed, regulator automatically leaves this menu (it shows T4 temperature in hot water tank). If you have changed the values and you haven't left the set-up menu, entered values are not effective.

TEMPERATURE DISPLAY:

During normal use display shows "T4" temperature which is the temperature of water in upper part of hot water tank. If you press "T1" key, the display shows temperature in collectors (T1). Temperature remains displayed until the key is pressed.

If you press "T2" key the display shows temperature of lower part of hot water tank (T2). Temperature remains displayed until the key is pressed.

If you press "T3" key, the display shows temperature in boiler (T3). Temperature remains displayed until the key is pressed.

WARNING!

Regulator reaction time is 5 sec. max., therefore after each change of temperature you must wait for 5 sec. to see the change on the display.


Display of Sensor Errors:

Errors of sensors (short circuit, interrupted sensor) are listed on the display. If the sensor is short circuited the display shows "Er2" and if it is interrupted "Er1". For T4 sensor this is permanently shown and for other sensors you must press "T1", "T2" or "T3" keys.

If T1 or T2 sensor is faulty, collector heating circuit is inoperative and after-heating circuit operates normally in automatic mode.

If T3 or T4 sensor is faulty, after-heating circuit is inoperative and collector circuit operates normally in automatic mode.

USE OF SELECTOR SWITCH FOR MANUAL CONTROL



WARNING!

ON1, ON2 and OFF positions are used only for **operation tests** of pumps and maintenance disconnection of pump operation when charging and venting the system, but not during normal operation. OFF position does not enable galvanic separation from mains. When replacing the pump, disconnect supply voltage!